

ADA/Outswing Threshold Prep



No Threshold Prep



Standard Inswing Threshold Prep



STANDARD HEIGHT TO ADA HEIGHT

You can take a standard length frame and remove 13/16" off the bottom of the frame and make the frame ADA length with the proper threshold preps.

